

# Sebastian Wrong/ FONT CLOCK

Model G100

- 1/ Remove all rear case covers.
- 2/ Minute flaps must be set on zero before adjusting the hour flaps.
- 3/ Set to the correct 24 hour by pressing down the second lever located at the back of the clock.
- 4/ Repeat item 2/ to set to the correct minute.
- 5/ Ensure that the two LR20 batteries are correctly inserted and switch on.  
The red LED light located in the front of the dial should flash.
- 6/ Replace the rear case covers.

Established  
The logo for Established & Sons features the word 'Established' in a serif font above the word '& SONS' in a larger, bold serif font. A decorative flourish or scrollwork element is positioned to the left of the ampersand. Below the main text, the words 'British Made' are written in a smaller, sans-serif font.  
British Made

