

Sebastian Wrong/ FONT CLOCK

Model G225

Established
 **SONS**
British Made

- 1/ Remove all rear case covers.
- 2/ Minute flaps must be set on zero before adjusting the hour flaps.
- 3/ Set to the correct 24 hour by pressing down the second lever located at the back of the clock.
- 4/ Repeat item 2/ to set to the correct minute.
- 5/ Set to the correct date by pressing down the lever located directly behind the date flap.
- 6/ Set to the correct day; repeat item 5/.
- 7/ Set to the correct month: repeat item 6/. Note that the clock requires setting for the correct Leap Year, therefore please note the number located on the right hand side of the month flap, for example, 1-4 and set to the table listed below:
No. 1 for years 2005/ 2009/ 2013/
No. 2 for years 2006/ 2010/ 2014/
No. 3 for years 2007/ 2011/ 2015/
No. 4 for years 2008/ 2012/ 2016/
Example: 'JAN' with '4' for the year of 2000.
- 8/ Ensure that the two LR20 batteries are correctly inserted and switch on. The red LED light located in the front of the dial should flash.
- 9/ Replace the rear case covers.

