


ASSEMBLY INSTRUCTIONS



Milton Adjustable Floor Lamp Item # 91025 -EU

INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT, DO NOT INSTALL. ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

1. Carefully remove all parts from the carton.
2. Join parts (D), (E) & (F) together by tightening washer (G) and nut (H) to threaded rod at bottom of pole (D). Tighten with T-wrench (K) provided.
3. Pull the wire from wire exit hole until tight.
4. Attach the handle of shade (A) to socket tube (B).
5. Insert light bulb into lampholder.
6. Plug lamp into wall outlet.

ADJUSTMENT INSTRUCTIONS

To adjust the lamp height, hold the lower pole (D) steadily, pulling or pushing the upper inner pole (C) up or down to desired height.

CAUTION:

If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.

DISPOSAL:

Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities. Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being.

*** Clean with a dry, soft cloth only. Use no harsh abrasives or chemical agents.