
instruction manual tramonto 03

valerie_objects

V9022102


luminaire specs
TYPE wall lamp
SWITCH remote dimmable handswitch
BULB led strip 8 watt/meter - 2500lm- cri95
IP 20
plug (Type F) for wall socket connection




safety directions

Please read the instruction manual carefully before installing or using this product. Keep this user manual for further reference / two persons needed for installation.

- 1. The luminaires may only be installed by authorized and qualified technicians according valid regulations for electrical istallation.
- 2. Maintenance of the luminaires is limited to their surfaces. During maintenance no moisture should come into contact with any areas of the terminal connections or voltage control parts.
- 3. Take account of the minimal separation distance from other objects and the room required around the fitting.
- 4. If in any doubt, consult a professional, taking local installation requirements into account. Some countries stipulate that lighting may be installed only by registered installers.
- 5. Clean with a clean, dry cloth or brush, use no solvents or abrasives. Avoid dampness on all electrical components.
- 6. Take account of all available technical information.
- 7. If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufaturer or his service agent or a similar qualified person in order to avoid a hazard.







1x set of plugs and screws (check with a technician if the plug is appropriate for the type of wall)

* determine the preferred position of your Tramonto wall lamp 03




* drill 2 connection holes > follow indicated grid

- > advised to be installed by a technician
- > use the correct plug for the type of wall
- > respect the drill diameter indicated on the plug




* secure the cable at the backside

> depending on the positioning of the Tramonto wall lamp the preferred cable outlet point needs to be fixed using a simple household tape at the back side



step **01** / activate remote control by inserting the requested 3 volt battery type cr2032 (battery not included in packaging)

step **02** /plug the lamp in the wall socket (compatible with plug type F)



step 03 / the first 10 seconds push from top to down 1 > 2 > 3 on the remote control.

A blinking signal of the led strip indicates the lamp is connected with the remote control.

