



MATCH POINT ceiling recessed

INSTALLATION INSTRUCTIONS | JUNE 2026



Driver must be powered off before connecting the cables.

Before connecting the luminaire/LED module to the driver please make sure the driver is not powered but disconnected from the mains. The driver can only be powered when the luminaire/LED module is already connected. Disregarding this instruction might damage or even destroy the luminaire/LED module.



DIMENSIONS

1.0			
1.0 ↑ IP44			



MOUNTING INSTRUCTION

- 1 Make a hole in the ceiling according to the prescribed dimensions.
- 2 **POWER CONNECTION**
Always use a driver according to the specifications of the LED module.
Single connection
220-240V

Multiple connection
220-240V
- 3 Push the springs upwards and insert the fixture in the ceiling hole.

MATCH POINT ceiling recessed


INSTALLATION INSTRUCTIONS | JUNE 2026



DISMOUNTING INSTRUCTION


- Light source
- 1 Take the luminaire out of the ceiling hole and unplug the wires.
 - 2 For IP44: Break the glass.
 - 3 Take out the snout and remove the lens.
 - 4 Remove the screws and take out the light source.

for 1.0



The light source is replaceable by Wever & Ducré or by a professional with explicit authorisation. For more information please contact your local Wever & Ducré customer service point.

for 1.0 ↑ IP44



The light source is not replaceable.



Use green electricity to light up your luminaire.