

7

Design by Dark studio for DARK

Assembly Doctor for SANGHA 80






- 1. Screw the gripper bodie onto the ceiling.
- 2. Turn the adjuster into the gripper body.
- 3. Put the lamp frame into the body.
- 4. Insert the cables through the holes in the lampframe. Lock the cable on the preferred height.
- 5. Mount the ceiling bracket with 2 screws onto the ceiling.
- 6. Adjust the power cable of fixture to the preferred height and fasten the strainrelief.
- 7. Connect the power supply and close the ceiling base with the 3 hexagonal screws.
- 8. (Re)place lamp. Respect the maximum wattage.




Dark at night Vliegplein 43 - 9991 Maldegem Belgium - Europe

tel +32(0)50/71.81.40 fax +32(0)50/71.81.38 mail info@dark.be

Lamp possibilities:









3