

PREAMBULE & SÉCURITÉ

Veuillez lire ces instructions soigneusement . En cas de doute, nous recommandons de consulter un électricien qualifié. Les produits AZIMUT INDUSTRIES ne doivent pas être modifiés sous réserve d'annuler la garantie constructeur. Pour usage intérieur seulement. IP 20. Classe 2. CE.

Le projecteur mobile est fixée à la base par un aimant puissant, ne pas laisser l'aimant entrer en contact avec les bande magnétique, les écrans d'ordinateur et de télévision. Ce produit ne doit être employé qu'avec le transformateur fourni ou recommandé.

INFORMATIONS GÉNÉRALES

o Le modèle AZIMUT 1969 halogene est un luminaire portatif fourni avec un câble secteur et une ampoule PAR 36 WFL.

REPLACEMENT DE L'AMPOULE

Le réflecteur fait partie de l'ampoule : sur les séries 1969 employez une ampoule de type PAR 36, 12V- 30W Max.

Débranchez l'alimentation secteur.

1. Enlevez l'entourage externe qui maintient l'ampoule.
2. Déconnectez le raccordement électriques secondaire au dos de l'ampoule puis remplacez l'ampoule.
3. Remplacez l'entourage métallique externe par clipsage.

TECHNICAL INFORMATION AND INSTALLATION INSTRUCTIONS

ENGLISH

INTRODUCTION & SAFETY

Please read these instructions carefully. In case of doubt, we recommend consulting a qualified electrician. The products AZIMUT INDUSTRIES should not be modified lest the guarantee of the manufacturer be annulled. For internal use only. IP 20. Classify 2. EC.

The mobile projector is fixed at the half-sphere base by a powerful magnet; do not let the magnet come into contact with magnetic tapes, or computer or television screens. This product should be used only with the transformer provided or recommended, in accordance with the power of the selected light bulb.

GENERAL INFORMATION



The model AZIMUT 1969 halogen is a portable lamp provided with a power cord and a light bulb PAR 36 WFL

REPLACING THE LIGHT BULB

The reflector forms part of the bulb: on the series 1969 use a bulb of the type PAR 36, 12V - 30W max.

Disconnect the power cord from the power supply.


1. Remove the external metal circle, which holds the bulb.
2. Disconnect the secondary electric connection at the back of the bulb. Replace the bulb.
3. Put back the external metal circle by clipping.

			
10213(White) 10212(Black) 10215(Grey) 10214(Red)	10218(Orange) 10216(Green) 10210(Chrome)		

Azimut | 1969 Halogène

FRANCAIS / ENGLISH / ESPANOL / ITALIANO / DEUTSCH

REPLACEMENT DE L'AMPOULE / REPLACING THE LIGHT BULB / CAMBIO DE LAMPARA O BOMBILLA / SOSTITUZIONE DELLA LAMPADA / AUSTAUSCH DER GLÜHBIRNE



INFORMATIONS / INFORMATIONS / INFORMACIÓN / INFORMAZIONI / INFORMATIONEN SECURITE / SAFETY / SEGURIDAD / SICUREZZA / SICHERHEIT

